


UT-65208F系列 带串口网管型以太网交换机 说明书

一、概述

UT-65208F	4	(RS232/485/422)
console	CLI	
EMC		-40~85



二、面板描述

UT-65208F-6T2SC-4DF-MNF

5.2

5.2.1

(50 62.5 m)

1	9 console
2	10 100Base-X
3	11 100Base-X
4 Default	12 10/100Base-T(X)
5	13 10/100Base-T(X)
6 P1	14 RS485/422
7 P2	15 RS485/422
8	16 RS485/422

FC

SC


ST

key

5.2.3

FC

FC



六、LED指示灯

RUN		
P1~P2		
1~4		
1~8		
ALM		

七、安装指导

7.1

7.2

7.3