

: UT-RD-PRE-000180

**Model: UT-850N**

(            USB    RS-485/422            )

\_\_\_\_\_

# UT-850N

## USB

### 1.

z UTEK  
 z  
 z Logo 

### 2.

z UT-850N  
 z VER: 01

### 3.

z USB RS-485/422

### 4.

1 USBV1.1 EIA RS-485 RS-422  
 2 USB VCC DATA+ DATA- GND FG  
 3 RS-485 T+ T- GND  
 4 RS-422 T+ T- R+ R- GND  
 5 2 4  
 6 ,  
 7 300-921600bps,  
 8 32 RS-422 RS-485  
 9 RS-485/422 1200 (9600bps ),USB 5  
 10 15000V  
 11 USB A ,DB9  
 12  
 13 35mm× 20mm× 69.5mm  
 14 -20 75 5% 95%  
 15 0-1200 921600bps-9600bps  
 16 Win98/Win2000/WinXP/Vista/Win7/Win8/8.1/10/Linux

### 4.1

z Prolific PL2303TA

## 5.


## RS-485/RS-422

DB9 (PIN)		RS-422	RS-485
1	T/R+	(A+)	RS-485 (A+)
2	T/R-	(B-)	RS-485 (B-)
3	RXD+	(A+)	
4	RXD-	(B-)	
5	GND		
6	N/A		
7	N/A		
8	N/A		
9	N/A		

## 6.

## 7. ( )

8.



9.

10

UT-850N	1PCS
	1PCS
	1PCS
USB	1PCS

11



:

12

-40 +85 , 5% 95%

13

/ /

14

15