



**UT-2212/3212 RS-232**

DB9	UT-2212 Remote	UT-3212 Remote
1		
2	SIN (RXD)	SIN (RXD)
3	SOUT (TXD)	SOUT (TXD)
4	DTR	
5	GND	GND
6	DSR	
7	RTS	RTS
8	CTS	CTS
9		

**UT-2212/3212 RJ-45**

RJ-45	UT-2212	UT-3212
1	1	VCC
2	2	GND
3	3	1
4	4	2
5	5	3
6	6	4
7	7	5
8	8	6







-40 +85 , 5% 95%