

USB TYPE-C RS-485/422

: _____ : _____ _____

1.

- UTEK
-
- Logo 

2.

- UT-890-TC
- VER: 01


3.

USB RS-485/422

4.

5.

DB9 针型 (PIN)	输出信号	RS-422全双工接线	RS-485半双工接线
1	T ⁺ R	-(A ⁺)	RS-485(A ⁺)
2	T ⁻ R-	-(B ⁻)	RS-485(B ⁻)
3	R ⁺ N ⁺	-(A ⁻)	RS-
4	R ⁻ N ⁻	-(B ⁺)	RS-
5	GND	-(GND)	-(GND)
6	N/A		
7	N/A		
8	N/A		
9	N/A		



DB9 针型
DB9 针型




A12	A11	A10	A9	A8	A7	A6	A5	A4	A3	A2	A1
GND	RX2+	RX2-	VBUS	SBU1	D-	D+	CC	VBUS	TX1-	TX1+	GND
GND	TX2+	TX2-	VBUS	VCONN			SBU2	VBUS	RX1-	RX1+	GND
B1	B2	B3	B4	B5	B6	B7	B8	B9	B10	B11	B12

6.



7.



8.

:

9.

10. / /

11.

12.