

UT-885

USB

1.

- UTEK
- Logo 

2.

- UT-885
- VER: 01

3.

- USB RS-485/422

4.

1	USBV1.1	1.0			USB2.0,	RS-485	RS-422	TIA/EIA
2	USB	VCC	DATA+	DATA-	GND	FG		
3	RS-485	T/R+	T/R-	GND				
4	RS-422	T+	T-	R+	R-	GND		
5					2		4	
6								
7		300-921600bps						
8					32	RS-422	RS-485	
9		RS-485/422	1200	(9600bps)	USB		5	
10		600W			± 15KV			
11		USB	A		RS-485/422	5Pin		
12					PWR	TXD	RXD	
13								
14		62mm× 33mm× 16mm						
15		-40	85		5%	95%		
16		0-1.200	921600bps-300bps					
17		Windows95/98/2000/xp/Vista/Win7/8/8.1/10			IMAG			

4.1

- FTDI FT232RL

5.

RS-485/RS-422

DB9 (PIN)		RS-422	RS-485
1	T/R+	(A+)	RS-485 (A+)
2	T/R-	(B-)	RS-485 (B-)
3	RXD+	(A+)	
4	RXD-	(B-)	
5	GND		

6.



7.

fl t

8.



9.



10

	1PCS
	1PCS
	1PCS

11



12

-40 +85 , 5% 95%

13 # #

14

15